



Version 1.0 17.05.18

www.geovent.dk

1.0 General safety precautions

IMPORTANT – Please study all the instructions before mounting and commissioning.

Please keep these instructions in a safe place and instruct all users in the function and operation of the product.

Installation and service should only be implemented after studying the wiring diagram thoroughly.

Avoid the dismantling of any factory-mounted parts, since it impedes the commissioning of the equipment.

All electrical installations must be carried out by an authorised electrician.

1.1 Danger

Dismantling parts on the MultiBox whilst in operation could be deadly dangerous.

Always disconnect the MultiBox from the mains, when removing the cover.

2.0 Adjustment of parameters

The MultiBox contains sevaral software programs, which controls how the MultiBox behaves. The MultiBox is by default set to 530, which is the program that is to be used in 9 out of 10 situations

- 1. Connect the MultiBox to 230 Volts as shown in the diagram
- 2. The Display will show "P0" on power-up
- 3. Press "ENTER" and select the appropriate soft ware program by scrolling with the "+" and "-" keys and the press "ENTER" once more.
- 4. Shift to P1 (the set point parameter) by using the "+" key and the press "ENTER" – adjust the value to your desired set point pressure (in Pascals) and press "ENTER" once more.
- 5. Use the "+" until you get to P10.
- 6. Keep the "ENTER" key pressed until you get a beep (tells you that the changes you have made are now saved in EEPROM).
- In case of failure cut the power for at least 20 seconds and put it back on. The MultiBox is now reset and you must start the programming procedure again.

Tabel of general FV56X parameters					
P75	Service timer	0	0-36	0=Off 1-36=months between service	
P76	Call service		Max 16 letters	Press and hold arrow down when connecting main power to type service message	
P77	Reg volt start	5V	0-10V	Regulator start up voltage	
P78	Reg delay start	5	0-240	Regulator start up time in seconds	
P92	Start position	0	0-1-2	0=closed, 1=open, 2=frees	
P93	Zero calibration	No	Yes	Calibration of pressure zero (pa)	
P94	Manual start/ stop	Yes	Yes No	Yes= Manual start No=Auto	
P95	Alarm delay	10	3600	Time delay before alarm signal	
P96	Language select	DK	GB	select DK or GB language	
P97	Disable alarm sound	0	0-1	Disable alarm sound when P97=1	
P98	PIN code	0	2211	PIN code on / off	
P99	Parameter Reset	No	Yes	Yes = Reset all parameters	
P00	Select of version	550	Table 1	Software version selection	

The software is applied for PID feedback regulation of process air extraction by means of frequency inverter or electric or pneumatic damper. The regulator PID signal can be inverted, and thereby have opposite direction. The Transmitter has 0-10V signal for calculated air extraction flow, and slave control of balanced Inlet air.

The following start-up procedure is recommended:

- Installation according to diagram below
- Green or Red Alarm diode when T3 is active
- Select software V530 or V630 in Parameter P00
- Connect one pressure sensor tube to ventilation ducting, or 2 sensor tubes to a flow meter
- Select desired regulator setpoint (Pa) in P01
- Select min. and max. alarm limits in P02 and P03
- Control signal in T10 can be inverted in P16.
- Terminal T10 is connected to freq. inv. or damper
- Terminal T8 with slave signal for balanced inlet air is connected to inlet air frequency inverter
- Terminal T9 with flow signal (I/s) can be connected to Sumbox such as version V670 or V675.
- Max fan capacity (50 Hz) is entered into P14
- Controller start in T4 or pres ESC (when P94=yes).

After start-up the following adjustments are possible:

- Adjust PID regulator: higher P06-value will speed up the regulator, and higher P07-value will moderate the regulator and reduce instability
- Adjust P22 and P23 to max Room and Inlet air flow
- T8 has 0-10V signal for Inlet air slave control
- T9 has 0-10V signal for flow rate transmitter The regulator maintains the actual set point as indicated in P10, and transmit 0-10V signals for flow rate(T9) and slave control of Inlet air (T8) with frequency control

Parameter list

Par.	Label	Def.	Max	Def	Max	Description
P00	Model number	530	530	630	630	Software version number
P01	Setpoint+pressure	1000	5000	100	1000	Adjust PID setpoint + pressure
P02	Min. alarm limit (Pa)	200	4999	20	999	Monitor alarm min. limit (Pa)
P03	Max. alarm limit (Pa)	5000	5000	1000	1000	Monitor alarm max. limit (Pa)
P04	Time delay (sec)	10	3600	10	3600	Time delay to shut down
P05	Neutral zone (Pa)	3	1000	3	1000	Neutral zone from set point
P06	P-factor (PID)	3	200	3	200	Regulator P-factor (speed)
P07	I-time (PID) (sec)	3	1000	3	1000	Regulator I-time (moderation)
D10	Pressure+setpoint	0	5000	0	1000	Actual press.+setpoint values
P14	Max flow for T10	1000	9999	1000	9999	Max capacity (l/s) main fan
P16	Invert PID signal	No	Yes	No	Yes	No = normal PID ; Yes = invert
D18	Flow display (l/s)	0	-	0	-	Flow with K-factor in P17
P22	Max Room flow	1	9999	1	9999	Room fan max capacity (l/s)
P23	Max Inlet flow	1000	9999	1000	9999	Inlet fan max capacity (l/s)
P24	Residual flow	0	9999	0	9999	Residual fan max capacity
D49	Display T10 (V)	0	-	0	-	0-10V value from PID (V)
D50	Display T9 (V)	0	-	0	-	10-0V Room air value (V)
D51	Display T8 (V)	0	-	0	-	0-10V Inlet air value (V)
P52	Min. limit T10 (V)	0	9	0	9	Adjust voltage limit for T10
P53	Max. limit T10 (V)	10	1	10	1	Adjust voltage limit for T10
P54	Min Limit T9 (V)	0	9	0	9	Adjust voltage limit for T9
P55	Max limit T9 (V)	10	1	10	1	Adjust voltage limit for T9
P56	Min Limit T8 (V)	0	9	0	9	Adjust voltage limit for T8
P57	Max limit T8 (V)	10	1	10	1	Adjust voltage limit for T8
P73	Flow rate (10V)	1000	9999	1000	9999	Flow (I/s) limit T9 at 10V output







Quick guide for frequency inverter setup.



Access parameter list.







Press menu and select Par L



Now it is possible to scroll through the parameter list using arrows. (Shown: example)



Motor data setup

Setup the motor's rated voltage as indicated on the motor label. For example 400V	LOC 9905 s
Setup the motor's rated current as indicated on the motor label. For example 2,6A	LOC 9906 S
Setup the motor's rated frequency as indicated on the motor label. For example 50Hz	LOC 9907 S
Setup the motor's rated speed as indicated on the motor label. For example. 2830 rpm	LOC 9908 s
Setup the motor's rated power consumption as indicated on the motor label. For example 4Kw	LOC 9909 s

Operation Limits

Setup the allowed current. In many cases the same as indicated on the label on the motor. For example. 2,6A

Setup minimum frequency. Set at 15Hz. If set lower, both fan and frequency inverter may suffer damage.

> Set max. frequency. Set at max allowed frequency for the current fan.



Ramp time setup.

Setup ramp up time. Normally about 20 seconds. (Ramp time correlates with fan size – the larger the fan, the longer the ramp time) LOC 2202 s

PAR

FWD

Setup ramp down time. Normally about 50 seconds (Ramp time correlates with fan size – the larger the fan, the longer the ramp time

Setup max reference.

Setup the value(Hz) of max reference voltage (10V). If you want the fan to run at for ex. 55Hz set it at 55Hz. (If you do not set this parameter the fan will not run faster than 50Hz)



This is a quick guide for setting up the frequency inverter with the minimu required settings. These settings apply to a typical Geovent product constellation, and are not directly applicable for use with other products. For settings of other parameters/macros and detailed explanation hereof, see the instructions manual from ABB.





Quick guide til opsætning af frekvensomformer.

OBS: Styres der med Multibox III skal styringsformen indstilles til "AUTO".

"Hand"	=	Styring via. frontpanelet.
"Auto"	=	Ekstern PID styring.



Adgang til parameterlisten.

Tryk menu.

Vælg "Primære indstillinger".

Her kan du vælge hvad du vil indstille, på de følgende sider vil du se de indstillinger vi anbefaler som minimum.

Aut	o 🌈 ACH580	15.6 H	Ηz
П	utputfrekvens z	0.00	
	lotorstrøm	0.00	•
B	enyttet motorhastighed /min	0.00	
Ind	stillinger 12:21	Men	u

Auto	C ACH580	15.6 Hz
Hove	dmenu ———	
\$	Primære indstillinger	-
	1/0	*
\sim	Diagnostik	•
Afslu	t 12:21	Vælg

Auto	C ACH580	15.6 Hz
Primær	e indstillinger —	
Hurtig i	ndstilling af HVAC	
Start, s	top, reference	
Motor	and the second second	•
Rampe	r	*
Grænse	er	
Tilbage	12:21	Vælg

Opsætning af motordata.

Under "primære indstillinger" vælges motor.	F
	1
Her indstilles motorens nominelle strøm som angivet på	Γ
mærkepladen på motoren. Feks. 2,6A	
	-
Her indstilles motorens nominelle hastighed som angivet på mærkenladen nå motoren – Feks, 2830 o/m	
	L
Her indstilles motorens nominelle spænding som angivet på	Г
mærkepladen på motoren. Feks. 400V	
Her indstilles motorens nominelle frekvens som angivet på	Γ
mærkepladen på motoren. Feks. 50Hz	
Her indstilles motorens nominelle effekt som angivet på	
	L
Opsætning af grænser.	
Under "Primære indstillinger" vælges "grænser".	P
	T

Her indstilles minimum frekvens. Indstilles til 15Hz, sættes den under vil både ventilator og frekvensomformer kunne tage skade.

Her indstilles maximum frekvens. Indstilles til den max tilladte frekvens for den aktuelle ventilator.

Her indstilles den max tilladte strøm. I mange tilfælde vil dette være det samme som angivet på mærkepladen på motoren. Feks. 2,6A



Strøm

Hastighed

Spænding

Frekvens

Effekt

Auto	C ACH580	15.6 Hz
Primære	indstillinger —	
Hurtig inc	Istilling af HVAC	•
Start, sto	p, reference	
Motor		•
Ramper		*
Grænser		•
Tilhage	12.23	Vælo

Minimum frekvens

Maksimum frekvens

Maksimum strøm

Opsætning af rampetider.

Under "Primære indstillinger" vælges "Ramper".

Her indstilles rampe op tiden. Indstilles normalt til ca. 20 sekunder.

Her indstilles rampe ned tiden. Indstilles normalt til ca. 50 sekunder.

Opsætning af max reference.

Under "Primære indstillinger" vælges "Start, stop, reference". På næste side vælges "Primært automatisk styrested" og på efterfølgende side "AI1 -skala"

Her indstilles værdien (Hz) af max reference spænding (10V). Skal ventilatoren køre eks. 55Hz indstilles denne til 55Hz. (Undlades dette vil ventilatoren ikke køre over 50Hz)

Opsætning af startbetingelser.

Under "Start, stop, reference" vælges "Aflåst/åbne".

Her vælges om man vil bruge DI4 som startbetingelse. Som standard er den indstillet til DI4. Vi anbefaler at fjerne fluebenet.

Dette er en quick guide til indstilling af de som minimum krævede indstillinger. Disse indstillinger er for en typisk standard Geovent produkt sammensætning, og kan ikke bruges direkte sammen med andre produkter. For opsætning af andre parametre/makroer og detaljerede forklaringer af parametre/makroer henviser vi til manualen fra ABB.

Primære indstillinger Hurtig indstilling af HVAC Start, stop, reference Motor Ramper

Accelerationstid

Decelerationstid

C ACH580 15.6 Hz Start, stop, reference 🔀 Indstillinger for basishandlinger XIndstillinger for basisstyring Valg af automatisk sty...: Kun primære Primært automatisk styrested Aflåste/åbne Tilbage 15:41 Vælo







Skala maks

MULTI COUPLING DIAGRAM - TERMINALS, MULTIBOX AND FREQUENCY INVERTERS



See manual - important parameters to adjust: Adjusting the frequency inverter:

Motor data: Typically parameter group 99 Ramp up/down: Typically parameter group 22. Typically parameter group 20 and 11 Frequency Max/Min:

switched from "I" to "U" This will change output from current to voltage. Remember to bridge GND and COM. IMPORTANT Jumper on the bottom (S1) must be

Quick guide - also see manual

PO: Version selector - select 530 (most common)
P1: Adjustment set point [Pa]
P2: Min. Alarm limits [s] at too low pressure
P3: Max. Alarm limit [s] at too high pressure
P10: shows current pressure.

Adjusting Multibox III:



MULTI COUPLING DIAGRAM - TERMINALS, MULTIBOX AND FREQUENCY INVERTERS

Warranty

Geovent A/S grants a warranty for products, which are defective; when it can be proved that the defects are due to poor manufacture or materials on the part of Geovent. The warranty comprises remedial action (reparation or exchange) until one year after date of shipment. No claims can be made against Geovent A/S in relation to loss of earnings or consequential loss as a result of defects on products from Geovent.

User liability

In order for Geovent to be capable of granting the declared warranty, the user/fitter must follow this Instruction Manual in all respects.

Under no circumstances may the products be changed in any way, without prior written agreement with Geovent A/S.

Declaration of Conformity



The manufacturer: GEOVENT A/S Hovedgaden 86 DK-8831 Løgstrup

hereby declares that:

The product: Multi Models: FV56

Multibox III FV56X

has been manufactured in compliance with the following directives and standards:

Safty:

EN60730-1:2012 – Automatic electrical controls for household and similar use. Part 1: General requirements.

EMC:

EN 61000-6-1:2007 – Electromagnetic compatibility (EMC) – Part 6-1: Generic standards - Immunity for residental, comercial and light-industrial envioronments.

EN 61000-6-3:2007 – Electromagnetic compatibility (EMC) – Part 6-3: Generic standards. Emission standard for residental, comercial and light-industrial envioronments.

EN 61000-6-3/A1:2011 – Electromagnetic compatibility (EMC) – Part 6-3: Generic standards. Emission standard for residental, comercial and light-industrial envioronments.

EN 61000-6-3/A1/AC:2012 – Electromagnetic compatibility (EMC) – Part 6-3: Generic standards. Emission standard for residental, comercial and light-industrial envioronments.

RoHS: Directive 2011/65/EU

Additional information:

The product meets the specifications in EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EC and is CE-marked.

The product is testet for normal use.

Date: 17/05 2018

Position: Name: Managing Director Thomas Molsen

Signature:

CE

