



Radial roof fans Series VRV vertical outlet

OPERATING INSTRUCTIONS

Original operating instructions

Contents: 0. Preface to the operating instructions

1. Basic safety instructions

- 1.1 Warning symbols
- 1.2 Conditions of use
- 1.3 Organisational measures
- 1.4 Residual risks

2. Transport and storage

3. Installation and commissioning

- 3.1 Instructions for the electrical system
- 3.2 Mounting options
- 3.3 Integration of the fan into the system / Mounting
- 3.4 Commissioning

4. Operation and maintenance

5. Repair instructions

- 5.1 Cleaning
- 5.2 Replacing the motor



6. Additional information for explosion-proof fans

7. Waste disposal

Declaration of Conformity

0. Preface to the operating instructions

These operating instructions are intended to familiarise users with series VRV fans so that they will be able to use them in accordance with their conditions of use.

These instructions contain important information relating to the safe, appropriate and cost-effective operation of these fans. Compliance with such instructions helps to avoid danger and to reduce repair costs and downtimes.

These operating instructions should be permanently available wherever the fan is installed. They must be read and observed by all persons involved with transportation, installation and start-up as well as with maintenance and repairs. In addition to the present operating instructions and legally binding accident-prevention regulations, the generally recognised technical rules and regulations pertaining to safe and competent execution of the work must be observed.

1. Basic safety instructions

1.1 Warning symbols



Information regarding cost-effective use of the fan



Details of do's and don'ts to prevent personal injuries and/or material damage

1.2 Conditions of use

The fans have been built according standard practices and recognised safety standards. Nevertheless, their operation may cause safety hazards or have an adverse effect on other machinery or other material assets. Therefore, it is extremely important that the conditions of use are observed and that the fan is in perfect working order.

The owner/user must comply with the conditions given below. The conditions stated in the manufacturer's brochure valid at the time the contract was concluded shall apply, unless specified otherwise by contractual agreements.

a. Requirements with respect to the conveying medium and the surroundings

- Compliance with the permissible temperature range, which depends on the type of fan, the operating speed and the construction materials
- The chemical resistance of the construction materials (particularly plastics) to the conveying medium must be tested
- For explosion-proof fans, the ignition temperature and the explosion hazard zone must be taken into account.
---> Section 6 "Additional information for explosion-proof fans"
- The density of the conveying medium must correspond to that of pure air. The medium must not contain foreign particles and has to be practically dustless. Higher dust loads or impure gases with a tendency to produce deposits may cause damage.
- Check that rainwater and condensate can drain freely through the provided outlet.
- The fan must be installed so that it is free of shocks and vibrations and must not be subjected to external mechanical loads.
- The compatibility of the fan with its surroundings must be checked. This applies, in particular, to the temperature, the chemical resistance and the explosion risk.



b. Requirements with respect to the mode of operation



- The fan must be operated at the speed (RPM or speed range) specified by the manufacturer.
- Parallel connection is permissible.
- Roof fans VRV can also be operated outside their characteristic range; however, this should be avoided to conserve energy.
- The technical conditions for electrical connection of the motor must be observed.
- Control of the fan speed is only possible for the fan models and control units specified by the manufacturer.



Non-compliance with the specified requirements constitutes a violation of the conditions of use. The manufacturer is not liable for damages resulting from such non-compliance.

1.3 Organisational measures



- All work with the fan must be carried out by appropriately instructed and reliable personnel.
- All work on electrical equipment (motors, control and regulating devices) must be carried out by qualified personnel (in compliance with DIN VDE 0105 or IEC 364)
- Repairs of explosion-proof fans must be carried out by the manufacturer or in consultation with the manufacturer.
- Maintenance intervals are to be specified by the owner/user, in consultation with the manufacturer, if necessary. In the event of any safety-related disturbances (e.g. fan runs unevenly, abnormal noises, visible external damage and defects), the fan must be taken out of operation and repaired.
- All repairs must be carried out with original spare parts. This also concerns the drive motor whose thermal behavior must be compatible with the plastic materials.
- Modifications of the fan that affect the safety are not permitted.
- The fan may only be operated if it is in a safe condition. This means that all protective and safety systems (e.g. electrical motor protection, safety screen) are in place and fully functional and that the fan is integrated into the system as specified in the project.

1.4 Residual risks



- ◆ Although the fans are of a reliable design and their manufacture is controlled by a quality assurance system, there is still a residual risk due to the possible rupture of the impeller, especially in cases in which it cannot be excluded that the conditions of use (see Section 1.2) are violated. Therefore, the vicinity of the fan must be secured so that personal injuries and material damage are excluded in the event of a malfunction or an accident.
- ◆ For high-powered fans, in particular, the sound pressure level may exceed the permissible limit value for sound immissions. Suitable measures must be implemented to protect persons within this zone from noise-related injuries. The sound immission data are given in the associated contract documents or the relevant brochures.



2. Transport and storage

- ◆ Loading work must be carried out by experienced personnel. Hoisting gear and hoist attachments with sufficient load-bearing capacity are to be used.
- ◆ The fan must be transported in the mounting position and properly secured against movement, tipping and collisions.
- ◆ When selecting a means of transport, attention must be paid to the fact that plastic fans can be damaged by collisions.
- ◆ If roof fans are to be stacked on top of each other, they must be in their original packaging and the stacking height must not exceed the height stipulated by the manufacturer.



3. Installation and commissioning


3.1 Instructions for the electrical system (for explosion-proof fans, see also Section 6.)

- ◆ The electrical equipment must be installed by a qualified electrician according to standard practices.
- ◆ Connect each motor to the mains supply via a motor protection device in accordance with DIN EN 60204-1. Set the bimetallic trip to the rated current. For pole-changing motors, install either two separate motor protection switches or one thermal winding protection (PTC thermistor --> special design TS).
- ◆ If the speed is regulated by a voltage regulator or a frequency converter, a bimetal switch does not provide adequate protection of the motor. In this case, use thermal motor protection (PTC thermistor --> special design TS; thermocontacts). Protection by calculating I^2t can also be used; this is included in most frequency converters.
- ◆ Check the electrical connection values (voltage and frequency). Connect the motor according to the enclosed circuit diagram (see the terminal box or the repair switch).
- ◆ For three-phase motors, use a star or delta connection, depending on the mains voltage and motor model. If star-delta switches are used, the mains voltage must agree with the lower voltage given on the motor type plate (e.g. motor 400/690V and mains 400V).
If a repair switch is installed, the motor is connected in the factory in a star or delta arrangement, depending on the planned voltage. During commissioning, check that the mains voltage is correct, and reverse the connections in the motor terminal box, if necessary.
- ◆ Before commissioning, measure the insulation resistance of the winding relative to earth. Dry and as-new windings have a resistance greater than 10 MΩ. If the measured value lies below 2 MΩ, dry the winding. More detailed information is given in the operating instructions for the motor.
- ◆ Check the direction of rotation of the fan by **switching it on briefly**. It must agree with the direction indicated by the red arrow on the housing. The inspection opening next to the arrow can be used as an aid (see the illustration below).

Attention! Even if the direction of rotation is incorrect, the radial fan will still transport the medium at a certain rate in the normal direction of flow. However, this operating mode may overload the motor.



- ◆ Measure the current consumption of the motor after commissioning and check it against the value given on the fan's type plate. If the current consumption is too high, check that the direction of rotation is correct.



How to check the direction of rotation

- ◆ Remove the protective cap next to the arrow indicating the direction of rotation
- ◆ Hold a strip of paper in the opening
- ◆ Switch on the fan briefly
- ◆ The flow must bend the strip of paper in the direction of the arrow
- ◆ If the direction of rotation is incorrect, swap over the two power cables
- ◆ Replace the protective cap and check that it is firmly seated

Uneven running of the fan is often a clear indication of deposits on the impeller. Check and clean immediately. The motors are usually equipped with permanently lubricated bearings with a service life of up to 50,000 hours, depending on the operating conditions. Relubrication is thus unnecessary. Replace defect antifriction bearings or renew the complete motor (see Repair instructions).

The fan must be inspected thoroughly after about 10 years. A specialist must then decide on its further use.

5. Repair instructions

Always switch off the fan before starting any work on it. Take measures to ensure that it cannot be switched on during repair work.

After repairs, proceed as for commissioning (see Section 3.4).

5.1 Cleaning

To clean the fan, detach the hood and the entire drive assembly (impeller, motor and motor support ring) from the lower section (see Section 5.2).

⇒ Cleaning fluids must not damage the construction materials, particularly the plastics.

⇒ Do not use hard objects for mechanical cleaning.

5.2 Replacing the motor


To replace the drive assembly or the motor, dismantle the fan into its main assemblies:

Dismantling

- VRV 100 ... 250 Remove the upper half of the housing including the motor cover,
- VRV 315 ... 400 Pull out the cooling air pipe, then take off the upper half of the housing and the motor cover.
- Disconnect the electrical connections on the motor
- Lift the drive out of the lower half of the housing. The drive assembly (motor, motor bracket and impeller) is available as a spare part and can be replaced at the site without any special tools.
- Remove the hub cap (caps glued or welded on must be destroyed)
- Unfasten the hub fastener and pull the impeller off the motor shaft (use a puller, if necessary)
- Replace the motor or repair according to the operating instructions for the motor.

Mounting

- Reassemble the fan in the reverse order. Replace the destroyed hub cap as well as the lock washer of the shaft lock.



6. Additional information for explosion-proof fans



Compliance with the conditions of use is the basic requirement for explosion-proof state of a fan.

Ensure that the fan has an approval for the respective explosion zone conditions (zone, equipment group, equipment class, explosion group, ignition temperature --> see the markings on the fan and the supplied documentation).

The following apply to fans fitted with motors with increased safety (EEx e):

permissible cooling air temperature -20 to +40 °C

permissible voltage tolerance +/- 5%,

permissible frequency tolerance +/- 2%

Integration of the fan into the system

In general, the fan should be installed so that it is protected against external mechanical loads. This particularly applies at temperatures below -5 °C because the impact strength of plastics is reduced.

Measures must be implemented to prevent foreign matter falling in or being sucked into the fan and the motor cooling fan. If necessary, safety devices, e.g. screens, must be installed in the system.

The air inlet connection must be gastight.

Modifications and attachments to the fan are only permissible after consultation with the manufacturer.

Before **commissioning** or start-up after a long downtime, carry out a thorough inspection of the fan. Any damage, such as housing cracks, contact between the impeller and the housing, strong vibrations or noises, must be remedied without delay. Do not operate fans and motors if they are damaged.

Instructions for the electrical system / motor protection (see also the operating instructions for the motor)

Requirements for the electrical connections:

Clearance distances between non-insulated parts > 10 mm.

Cable glands and sealing plugs must have an approval for explosion hazard zones

Reliable explosion protection of motors requires the installation of the correct motor protection system. Tripping devices must have an ATEX approval.

Motors with increased safety (EEx e):

A motor protection device with a current-dependent delay and an ATEX approval must be installed so that, in the event of an overload, it will disconnect the motor from the mains supply within the permissible heating period (t_E time). The motor can be additionally protected by a PTC thermistor. However, protection of the motor using only a PTC thermistor is not permissible.

Motors with a flameproof enclosure (EEx de):

Motor protection devices with a current-dependent delay and/or PTC thermistors (TS) can be used.

Motors with increased safety (EEx e) do not have an approval for operation with a **frequency converter**.

Motors with a flameproof enclosure (EEx de) can be operated in conjunction with special temperature monitoring of the converter with a PTC thermistor.

Inspection, maintenance and repairs

The fan must be inspected at regular intervals to maintain explosion protection and to recognise and remedy faults at an early stage.

The inspection intervals are to be specified by the owner/user depending on the respective operating conditions (soiling, operating time, temperature, etc.); however, after every 4,000 operating hours or every 6 months at the latest. It is advisable to document these activities in writing.

Main points of inspection and maintenance work:

- ♦ Cleaning of the housing, impeller and motor
- ♦ Check of smooth running (imbalance) and motor bearing (noise, vibrations); relubricate, if necessary
- ♦ Check that the impeller is rotating freely. Check the gap between the impeller and the housing
- ♦ Check that all screwed connections are firmly secured and that connected components and flange connections are gastight
- ♦ Check the state of the shaft seal (particularly if the internal and external explosion zones are different)
- ♦ Check the motor current and insulation resistance as well as the motor protection device
- ♦ Check the state of the electrical connections
- ♦ Check all other monitoring equipment

Work in potentially explosive atmospheres must be carried out with suitable and appropriately approved tools. It is prohibited to open the terminal box when the fan is operating. All work on the fan should thus be carried out in a non-energised state and only if the possibility of a potentially explosive atmosphere can be excluded.

Plastic parts must be cleaned with damp agents to avoid electrostatic charges.


Repairs of explosion-proof fans must be carried out by the manufacturer or in consultation with the manufacturer.

7. Waste disposal

MIETZSCH fans are built to last. Thus disposal issues only crop up after many years of operation. The individual components are not regarded as hazardous waste according to current legislation.

- ♦ Dispose of metal components (base, motor, screws, etc.) in the usual manner
- ♦ Clean plastic components and then dispose of them as normal waste

The owner/user must dispose of residual materials and deposits in the fan in an environmentally acceptable manner.



D

MIETZSCH GmbH Lufttechnik
Großenhainer Str. 137 - D 01129 Dresden

EG-Konformitätserklärung im Sinne der EG-Maschinenrichtlinie

Hiermit erklären wir, dass die nachfolgend bezeichnete Maschine aufgrund ihrer Konzipierung und Bauart sowie in der von uns in Verkehr gebrachten Ausführung den einschlägigen grundlegenden Sicherheits- und Gesundheitsanforderungen der EG-Maschinenrichtlinie entspricht. Bei einer nicht mit uns abgestimmten Änderung der Maschine verliert diese Erklärung ihre Gültigkeit.

Bezeichnung: **Radialdachventilator**
vertikal ausblasend

Maschinentyp: **Baureihe VRV**

Maschinen-Nr. / Baujahr: Siehe Typenschild

Einschlägige EG-Richtlinien:

EG-Maschinenrichtlinie (2006/42/EG)
EG-Niederspannungsrichtlinie (2006/95/EG)
EMV-Richtlinie (2004/108/EG)

Angewandte harmonisierte Normen, insbesondere:

EN ISO 12100-1, EN ISO 12100-2 und EN ISO 13857
- Sicherheit von Maschinen


EN 60204-1 Elektrische Ausrüstung von Maschinen

Ventilatoren in EX-Ausführung entsprechen zusätzlich:

Europäische Richtlinie 94/9/EG (ATEX)
EN 14986 Konstruktion von Ventilatoren für den Einsatz in explosionsgefährdeten Bereichen
EN 13463-1 und -5 Nichtelektrische Geräte für den Einsatz in explosionsgefährdeten Bereichen
EN 50014, EN 50018, EN 50019
Elektrische Betriebsmittel für explosionsgefährdete Bereiche

Angewandte nationale Normen und technische Spezifikationen, insbesondere:

VDMA 24167 Ventilatoren; Sicherheitsanforderungen VBG 5, VBG 5 DA Kraftbetriebene Arbeitsmittel


Rausch
Geschäftsführer

Dresden, den 25.02.2013

GB

MIETZSCH GmbH Lufttechnik
Großenhainer Str. 137 - D 01129 Dresden

EC-Declaration of Conformity as defined by the EC Council Directive on Machinery

Herewith we declare that the machinery designated below, on the basis of its design and construction in the form brought onto the market by us is in accordance with the relevant safety and health requirements of the EC Council Directive on Machinery.
If alterations are made to the machinery without prior consultations with us, this declaration becomes invalid

Designation: **Radial roof fan**
vertical outlet

Machinery type: **Series VRV**

Machinery -No. / Year of production : see rating plate

Relevant EC Council Directives:

EC-Machinery Directive (2006/42/EG)
EC-Low Voltage Directive (2006/95/EG)
EMC-Guideline (2004/108/EG)

Applied harmonized standards, in particular:

EN ISO 12100-1, EN ISO 12100-2 and EN ISO 13857
-Safety of Machinery

EN 60204-1 Electrical Equipment of Machines

Explosion-proof Fans additionally apply to:

European Directive 94/9/EG (ATEX)
EN 14986 Design of fans working in potentially explosive atmospheres
EN 13463-1 und -5 Non-electric equipment for potentially explosive atmosphere
EN 50014, EN 50018, EN 50019
Electrical apparatus for potentially explosive atmospheres

Applied national standards and technical specifications, in particular:

VDMA 24167 Fans; Safety requirements VBG 5, VBG 5 DA Accident Prevention Regulations 'Power Driven Tools'


Rausch
Manager

Dresden, 25.02.2013